



## Remember the Law!

All pedestrian paths of travel around work zones must be accessible and compliant with Federal, State and local laws, including the Americans with Disabilities Act (ADA).



## Work Zones & ADA Compliance

Pedestrian  
Accessibility  
in the Public  
Right of Way

**For more information  
contact:**

**ADA Coordinator & Disability  
Service Facilitator**

**Edmund Asiedu**

**Tel:** 929-441-9658

**Email:** [accessibility@dot.nyc.gov](mailto:accessibility@dot.nyc.gov)

[nyc.gov/dot](http://nyc.gov/dot)  
311



V1





## DOT POLICY

The New York City Department of Transportation (DOT) requires **accessible pedestrian paths through or around work zones. Pedestrians, including those with disabilities, need accessible and clear work-zone paths.**

**Contractors must take appropriate measures to ensure that work zones are properly protected. For visually or mobility-impaired people, blocked segments within the pedestrian path of travel can easily compromise their entire route.**



## ACHIEVING COMPLIANCE

### Alternate Pedestrian Paths

Contractors must provide alternate paths when the ordinary pedestrian accessible route, such as the sidewalk, is obstructed by a temporary work zone. At minimum, the path should be 5 feet wide with firm, detectable and continuous with barricades or other channeling devices.

### Barricades

Essential to pedestrian safety, barricades must be firm, detectable, and securely in place. Contractors must place barricades:

- Between pedestrian access routes and adjacent construction sites.
- Between pedestrian paths and vehicular traffic.
- At the bottom of a pedestrian ramp when an opposite ramp is blocked.
- In front of hazardous objects protruding onto pedestrian paths.

## ENSURING COMPLIANCE

### Helpful tips to achieve an accessible work-zone facility:

- Provide advance notice within ample distance of your work zone that allows pedestrians to make appropriate travel decisions.
- Maintain a continuous accessible path with proper barriers at all times through the entire work zone.
- Provide an accessible path to the immediate surrounding facilities.
- Maintain curb ramps and or temporary ramps clear of debris and accessible to all pedestrians at all times.
- Provide appropriate signage at curbs, crosswalks, intersections or any other area affected by your work zone.
- Provide work-zone information to help manage pedestrian flow through your temporary facility.
- Schedule and track routine sunrise and sunset inspections of your accessible path of travel.
- Comply with all requirements of the Manual on Uniform Traffic Control Devices (MUTCD).



### Surfaces

All surfaces of pedestrian access routes must be firm, stable and slip-resistant.

### Signage and Warnings

Place signage at nearest intersections surrounding a work zone. Signage and warning signs must be thoughtfully located to minimize backtracking.

**All contractors performing work on City streets should provide safe and convenient passage to all pedestrians.**

